

# Инструкция за актуализиране на детектор за фалшиви банкноти Safescan 155-S G2



1. Отворете web - браузър и влезте на адрес: <https://www.safescan.com/>.

От началната страница, изберете иконката със знамето в горния десен ъгъл и задайте „Bulgaria“ за държава.

**Safescan** Online Shop Dealers Company Customer Service

3-1192

**America**  
Canada  
Mexico  
United States

**Africa**  
Angola  
Cameroon  
Congo  
Cote d'Ivoire  
Ethiopia  
Ghana  
Kenya  
Morocco  
Mozambique  
Nigeria

South Africa  
Tanzania  
Tunisia  
Rest of Africa

**Asia**  
China  
Hong Kong  
Macau  
Malaysia  
Singapore

**Europe**  
Albania  
Austria


Belarus  
Belgium  
**Bulgaria**  
Croatia  
Cyprus  
Czech Republic  
Denmark  
Estonia  
Finland  
France  
Germany  
Greece  
Hungary  
Ireland  
Italy  
Latvia

Liechtenstein  
Lithuania  
Luxembourg  
Monaco  
Netherlands  
Norway  
Poland  
Portugal  
Romania  
Slovakia  
Slovenia  
Spain  
Sweden  
Switzerland  
United Kingdom

Rest of Europe

1 - 5 of 5 | Downloads per page: all

2. След отваряне на началната страница на уебсайта, изберете „**Customer service**“ от менюто в горната част на страницата.



The image shows a screenshot of the Safescan website homepage. The top navigation bar is black with white text. The 'Customer Service' link is circled in red, and a red arrow points to it from the right. Other navigation links include 'Online Shop', 'Dealers', and 'Company'. To the right of the navigation bar are icons for a search function, a shopping cart, a flag (representing currency), and a hamburger menu icon. Below the navigation bar, there is a grey banner with a 4.8-star rating and '468 Google reviews' on the left, and a link 'Need help? Please contact us.' on the right. The main content area features a large image of a cashier's counter with jars of straws, a coffee cup, and a card payment terminal. Below this image is a dark grey bar with four white icons and text: 'PROFESSIONAL SUPPORT', '3 YEAR WARRANTY', '20 YEARS OF EXPERTISE', and 'FREE CURRENCY UPDATES'. At the bottom, there are five product categories, each with an image and a label: 'Banknote Counters' (a machine counting a 5 Euro note), 'Counterfeit Detectors' (a small black device), 'Coin Counters & Sorters' (a large white machine with multiple compartments), 'Money Counting Scales' (a scale with a 20 Euro note on it), and 'Cash Drawers' (a black rectangular device).

3. Отваря се страница с меню в табличен вид.

4. Изберете „Downloads“ от графа „**Service & Support**“ в долната част на страницата.

The screenshot shows the Safescan Customer Service page layout. At the top is a navigation bar with the Safescan logo and links for Online Shop, Dealers, Company, and Customer Service. Below this is a header with the Safescan logo and the text 'CUSTOMER-SERVICE'. The main content area is a grid of six columns:

- Order**:> How to order online, Checking stock, Creating a Safescan Account, After you placed your order, Contact Form. More information button.
- Payment**:> VAT policy, Payment methods. More information button.
- Delivery & Returns**:> Shipping costs, Delivery times, Incorrect or lost orders, 14 day money-back guarantee, Defective on Arrival Policy, Return instructions, Returns costs. More information button.
- Warranty & Repairs**:> Warranty period, Product registration, Repair request, CE certification, WEEE Regulations.
- Service & Support**:> Safescan support center, TimeMoto support center, Contact Form, Remote Support Software, **Downloads** (circled in red with an arrow).
- Terms & Conditions**:> Terms & Conditions, Terms of use, Privacy Statement.

5. На екрана ще видите страница с 3 полета. Изберете последователно във всяко от тях, започвайки от ляво на дясно, следните опции:

**Safescan®** Online Shop Dealers Company Customer Service

4.8 ★★★★★ 468 Google reviews Need help? [Please contact us.](#)

**Safescan®** DOWNLOADS [Back to Customer service](#)

Find your product. See where your part-number is located.

**Category**

- Counterfeit Detectors
- Banknote Counters
- Coin Counters
- Money Counting Scales
- Cash Drawers and POS Safes
- Time Attendance Systems

**Product**

- Safescan 155i
- Safescan 155-S
- Safescan 155-S G2
- Safescan 185-S
- Safescan 30
- Safescan 35

**Part number**

- 112-0668
- 112-0691
- 112-0692
- 112-0693
- 112-0694
- 112-0732







1 - 6 of 6 | Downloads per page: all

**Standard European Currency Software - USB**  
Includes: EUR, GBP, CHF, SEK, NOK, DKK ⓘ  
Compatible with: Safescan 155-S (G2)  
Version number: EU-07 (26-09-2025)  
File size: 3.3 MB [Download](#)

**Standard European Currency Software - MicroSD**  
Includes: EUR, GBP, CHF, SEK, NOK, DKK ⓘ  
Compatible with: Safescan 155-S (G2)  
Version number: EU-07 (25-09-2025)  
File size: 702.7 kB [Download](#)

Safescan® Online Shop Dealers Company Customer Service


1 - 6 of 6 | Downloads per page: all

	<b>Standard European Currency Software - USB</b> Includes: EUR, GBP, CHF, SEK, NOK, DKK ⓘ Compatible with: Safescan 155-S (G2) Version number: EU-07 (26-09-2025) File size: 3.3 MB		<b>Standard European Currency Software - MicroSD</b> Includes: EUR, GBP, CHF, SEK, NOK, DKK ⓘ Compatible with: Safescan 155-S (G2) Version number: EU-07 (25-09-2025) File size: 702.7 kB
	<b>British / Northern Irish Currency Software - USB</b> Includes: EUR, GBP, SCT, NIR ⓘ Compatible with: Safescan 155-S (G2) Version number: U-06 (13-05-2025) File size: 3.4 MB		<b>British / Northern Irish Currency Software - MicroSD</b> Includes: EUR, GBP, SCT, NIR ⓘ Compatible with: Safescan 155-S (G2) Version number: U-06 (12-05-2025) File size: 664.1 kB
	<b>Eastern European Currency Software - USB</b> Includes: EUR, BGN, CZK, HUF, PLN, RON ⓘ Compatible with: Safescan 155-S (G2) Version number: EE-06 (11-05-2025) File size: 3.4 MB		<b>Eastern European Currency Software - MicroSD</b> Includes: EUR, BGN, CZK, HUF, PLN, RON ⓘ Compatible with: Safescan 155-S (G2) Version number: EE-06 (10-05-2025) File size: 677.5 kB

6. Придвижете се надолу по страницата, за да видите всички налични опции за „пакети“ от валути, които устройството може да поддържа.


7. Изтеглете пакета най-долу вляво с име „**Eastern European Currency Software – USB Includes: EUR, BGN, CZK, HUF, PLN, RON**“ с помощта на бутон „**Download**“.

8. Отваря се нов прозорец, на който следва да изберем отново **„Download“**.



The screenshot shows the Safescan website's 'Downloads' section. At the top, there is a navigation bar with links for 'Online Shop', 'Dealers', 'Company', and 'Customer Service'. Below this, the Safescan logo is displayed on the left, and the word 'DOWNLOADS' is on the right. A search bar is present. The main content area features a product listing for 'Eastern European Currency Software - USB' with a ZIP icon and a 'Download' button. A red arrow points to this button. Below the button, there is a description: 'USB software update for the Safescan 155-S G2. Includes improved counterfeit detection for Euro banknotes.' and technical specifications: 'Compatible with: Safescan 155-S (G2)', 'Version number: EE-06 (11-05-2025)', and 'File size: 3.4 MB'. A 'Back' link is at the bottom left. A dark banner at the bottom contains icons and text for 'PROFESSIONAL SUPPORT', '3 YEAR WARRANTY', and '20 YEARS OF EXPERTISE'.

9. На следващата страница, която се отваря, следва да изберете **зеления бутон „I have checked my part number, start my download“**, след което ще бъде изтеглен файл под формата на архив.






The screenshot shows the Safescan website's 'Downloads' section with an 'Attention required' warning. The warning text states: 'The selected download is for a specific part number. Installing software or firmware on a machine with a different part number may cause damage to that machine. Make sure you check the download.' Below the warning is a green button that says 'I have checked my part number, start my download.' A red arrow points to this button. The page layout is consistent with the previous screenshot, including the navigation bar, Safescan logo, and 'DOWNLOADS' header. The bottom banner features icons and text for 'PROFESSIONAL SUPPORT', '3 YEAR WARRANTY', '20 YEARS OF EXPERTISE', and 'FREE CU'. Below the banner, there are six categories of products: Counterfeit Detectors, Banknote Counters, Coin Counters And Sorters, Money Counting Scales, Cash Drawers And POS Safes, and Time Clock Systems.

10. Създайте папка и поставете и разархивирайте файла вътре в нея.

11. Свържете устройството с вашето компютърно устройство с помощта на **USB 2.0 mini A** кабел.

12. След успешна връзка, стартирайте файла с име „**Multi-Target Programmer 7.4**“. На екрана ще се отвори нов малък прозорец.




13. Уверете се, че устройството е изключено, след което задържайки бутон „Mode“ продължително време, натиснете средния бутон на устройството


еднократно (без да пускате „Mode“ бутона), докато устройството не влезе в програмен режим.



14. От появилия се прозорец на екрана на личния ви компютър, изберете бутон **„Load File“**.




15. Отваря се друг прозорец, позволяващ избирането на файл. Намерете папката с всички изтеглени файлове, която създадохте по-рано, изберете текстовия файл и натиснете бутон **„Отвори“**.



16. Изберете бутон **“Update Soft”**. Програмата ще започне да зарежда ъпдейта на устройството.

\* Изчакайте, докато цялата лента се изпълни докрай в син цвят.



17. Актуализацията е готова. Сменете работната валута на устройството с **“BGN”** и тествайте.